



## Twisted Cords

Running through the telephone cord are a number of delicate, flexible wires.

"Kinks" are formed when this cord is allowed to become twisted, and some of these wires may be bent or broken.

This means a "noisy" telephone line. You cannot hear or be heard as well. In fact, a twisted cord may cause a complete interruption of your service.

Keeping the telephone cord straight will give you greater satisfaction in the use of your telephone.